

# **DIESEL LUBRICITY PLUS**

## **DIRECTIONS:**

DIESEL LUBRICITY PLUS may be added to the fuel in the truck or it can be added to fuel in storage tanks.

### **TO TREAT STORAGE TANKS:**

Add DIESEL LUBRICITY PLUS to the storage tank before filling.

### **TO TREAT DIESEL IN THE TRUCK:**

Add DIESEL LUBRICITY PLUS to each fuel tank. One quart is sufficient to treat 250 gallons of fuel.

### **CAUTION:**

Combustible liquid. Keep away from heat and flame. DO NOT DRINK. Flash point: 100 F or higher. KEEP OUT OF REACH OF CHILDREN

## **SUPER CONCENTRATED LUBRICITY IMPROVER**

- \*1 gallon treats 1000 gallons
- \*Anti oxidant-to prevent rust & corrosion
- \*Prevents excessive pump wear
  - \*Ashless
- \*Adds lubricity to severely hydro treated fuels

**80L34 NET CONTENTS GAL(S)**

## **ADDITIONAL CAUTIONS:**

**EYES:** Irritating but does not injure eye tissue. If contact occurs, flush with water until irritation subsides. If irritation persists, get medical aid.

**SKIN:** Frequent or prolonged contact may irritate and cause dermatitis. If contact occurs, wash with soap and water.

**INHALATION:** May be irritating to respiratory tract, may cause dizziness or collapse. If inhaled, move to fresh air. Give CPR if unconscious and oxygen if needed once respiration is restored.

**INGESTION:** May cause nausea, vomiting and diarrhea. If ingested. DO NOT INDUCE VOMITING. Give water or milk. Keep warm and quiet. Seek medical aid.

## **TO REORDER:**

**PIC  
4408 Glenview Dr  
Haltom City, TX 76117  
(817) 281-1474 (800) 359-8031**